

Timing-Belt Reverse Unit 8 80 R50 II
Notes on Use and Installation

Content

General safety information	3
Correct use	3
Application	4
Technical Data/Scope of Supply	4
Fastening Options	5
Rounding the Profile Edges	5
Installation	6
Timing-Belt Tensioner	6
Tensioning the Timing Belt	6
Alignment of Timing-Belt Reverse Unit to the Profile	7
Synchronisation	7

General safety information

The data and the information contained in the Notes on Use and Installation are intended exclusively for product description and assembly. The information does not release the user from conducting their own assessments and checks. It should be noted that our products are subject to natural wear and tear as well as an aging process.

These Notes on Installation and Use include important information for the safe and appropriate use of the product. In the case of a sale, rent or other transmission of the product, the latter must be accompanied by the Notes on Use and Installation.

During the assembly, operation and maintenance of the driven linear unit, it must be ensured that all moving parts are secured against accidental switch-on or moving. Rotating and moving parts can lead to serious injury! Please make sure to read and observe the following safety precautions.

- Any work with or close to the driven linear unit must be performed under the motto "safety first".
- Switch the drive unit off before you begin a task close to the driven linear unit.
- Secure the drive unit against accidental switch-on, e.g. by installing signs near the switch or remove the fuse from the power supply.
- Do not reach into the working area of the moving parts of the driven linear unit while it is operating.
- Secure the moving parts of the driven linear unit against accidental contact by installing protective devices and enclosures.
- Please take note of the applicable regulations for accident prevention and environmental protection in the country of use and the workplace.
- Use item products only in technically perfect condition.
- Non-use of original spare parts leads to the expiry of the warranty!
- Check if the product has obvious defects.
- Use the product exclusively within the range of performance described in the technical data.
- Make sure all the safety devices belonging to the product are available, suitably installed and fully functional.
- You are not allowed to change the position of, avoid or disable safety devices.

The driven linear unit described here corresponds to the state-of-the-art and respects the general principles of safety at the date of printing of the present Notes on Use and Installation. Nonetheless, the hazard for personal injury and damage to property remains when the fundamental safety instructions and warning notices mentioned in the present Notes on Use and Installation are not observed. We accept no liability for any damage that may arise from them. In

the interest of further development, we reserve ourselves the right to technical changes. Keep the present Notes on Use and Installation readily accessible to all users. Please take notice of the superordinate instructions for use of the complete machinery or equipment. The general hazard warning refers to the whole life cycle of the partly completed machinery.

1. Transport Please note the transport instructions on the packaging. Make sure to leave the product in the original packaging and protect it from humidity and damage until assembly. Please note that moving parts are fixed and can cause no damage during transport.
2. Assembly Always switch the relevant system component off-circuit before you assemble the product or plug/unplug it. Secure the system against re-starting. Lay the cables and conducts so that they cannot be damaged and nobody can trip over them. Avoid places with risk of slipping, tripping or falling.
3. Putting into service Let the product acclimatise for some hours before putting it into service. Make sure the partly completed machinery is tightly and safely integrated to the complete machinery. Only put fully installed products into service.
4. During operation Allow the access to the direct operational area of the system only to people authorised by the operator. This also applies for downtimes of the system. Moving parts must not be accidentally actuated. In case of emergency, error or other irregularities, switch off the system and secure it against restarting. Make sure people cannot be shut in the system's danger zone.
5. Cleaning Close all openings with appropriate protective devices so that no detergent can enter the system. Use no aggressive detergents. Do not use a high-pressure cleaner for the cleaning.
6. Putting into service and maintenance Perform the required maintenance work in the time intervals described in the operating instructions. Make sure no connection line, connection or component is released until the system is under pressure and tension. Secure the system against restarting.
7. Disposal Dispose of the product according to the national and international provisions of your country.

Correct use

The driven linear unit is a product in accordance with the Machinery Directive 2006/42/EC (partly completed machinery). The driven linear unit can only be used in accordance with the technical data and safety regulations of the present documentation. The internal rules and guidelines of the country of use must be respected. Unauthorised structural changes to the driven linear unit are not permitted. We accept no liability for any damage that may arise from them.

- You are authorised to assemble, operate and maintain the drive linear unit only if:
- The driven linear unit has been integrated to the complete machinery according to the intended applications and safety requirements.
- You have read the Notes on Use and Installation carefully and understood them.

- You are qualified.
- You have the authorisation of your company.
- You exclusively use the original accessories of the manufacturer.

In case of unsafe and inappropriate operation of the driven linear unit, there is a danger of serious injury from crush and shear points.

Inappropriate use

The inappropriate use refers to applications differing from the use authorised by the Notes on Use and Installation and the appropriate use. We accept no liability for any damage that may arise.

Application




Timing-Belt Reverse Units 8 80 R50 II with multi-spline or bore are used to drive or reverse timing-belt R50 T10 for mounting linear units in conjunction with the guides, bevel gear boxes and drive units. It is mounted in the core bores of the Profiles 8 (Starting with 80x80 mm).

The timing pulley with multi-spline hub (Timing-Belt Reverse 8 80 R50 II VK32) has been pre-prepared for mounting drive units or multi-spline shafts and adapter shafts with multi-spline hub DIN ISO 14-6x26x32.

The timing pulley with bore $\varnothing 16$ H7 can be machined for other shaft/hub connections (reborable up to $\varnothing 36$ mm. $\varnothing 30$ mm with key).

The housing allows connection of coupling D80 VK32.

Technical Data/Scope of Supply



Timing-Belt Reverse Unit 8 80 R50, GD-Zn, black

One revolution corresponds to 280 mm

effective radius: 44.6 mm

Friction moment with 1‰ pre-tensioning of the Timing Belt: $M_f = 1.05$ Nm

Max. load: $M_D = 92$ Nm

Timing Belt length in the Timing-Belt Reverse Unit for

90° reversal: 220 mm

180° reversal: 300 mm

Pitch $p = 10$ mm

Number of teeth $z = 28$

Version 1 (Art. No. 0.0.426.19)

Ball-bearing timing pulley with multi-spline hub,

Hub geometry VK32 for Multi-Spline Shaft VK32 DIN ISO 14-6x26x32, hub length 75 mm


Version 2 (Art. No. 0.0.426.21)

Ball-bearing timing pulley with bore $\varnothing 16$ H7,

reborable up to max. $\varnothing 36$ mm,


hub length 75 mm

Fastening Options



Connection of Timing-Belt Reverse Unit 8 80 R50 II based on a profile height of 120 mm (return of the Timing Belt in the profile cavity) or a profile height of 80 mm with Standard-Fastening Sets 8. To do this, the Timing-Belt Reverse Unit is partially dismantled, secured to the profile and then refitted.

The emergence dimension of the Timing Belt is 80 mm.






90° reversal of Timing Belt R50 T10.

The opening for the Timing Belt is marked out on the inside and must be removed from the cap.

If for design reasons the Timing-Belt Reverse Unit is fitted without a cap, the length of the Timing Belt in the Reverse Unit reduces by 10 mm.

Rounding the Profile Edges



To protect the Timing Belt against damage, the profiles must be rounded at the joint to the Timing-Belt Reverse Unit.

Installation






Illustration similar

To insert the Timing Belt (Art. No. 0.0.426.03) in the Timing-Belt Reverse Unit 8 80 R50 II VK32 ⑳, the Unit has to be opened. To do so, unscrew and remove all the screws in the Timing-Belt Reverse Unit 8 80 R50 II VK32 ⑳. The two halves of the Timing-Belt Reverse Unit 8 80 R50 II VK32 ⑰ ⑲ housing are separated by gently tapping the hub of the Pulley Wheel (use plastic rods).

Under no circumstances must the two halves of the housing be separated by inserting a hard object such as a screwdriver or similar tool between the two halves. The floating bearing end of the Timing-Belt Reverse Units 8 80 R50 II VK32 ⑲ is screwed in place in the core holes of the Support Profiles. Place the Timing Belt around the Pulley Wheels in the required direction. The two halves of the housing of the Timing-Belt Reverse Unit 8 80 R50 II VK32 ⑰ ⑲ are then screwed together again. The end of the Timing Belt now has to be cut to the exact length and the end placed in the loose half of the Timing Belt Tensioning Set 8 R50 .

- ⑩ Dowel ISO 8734-6m 6x28
- ⑪ Profile 8 200x80
- ⑫ Timing belt R50 T 10
- ⑬ Standard-Fastening 8
- ⑭ Hex. Socket Head Cap Screw DIN 912-M8x20
- ⑮ Button-Head Screw M5x16
- ⑯ Ball-bearing timing pulley with multi-spline hub
- ⑰ Fixed Bearing
- ⑱ Timing-Belt Reverse Unit 8 80 R50 II VK32 Cap
- ⑲ Floating Bearing
- ⑳ Timing-Belt Reverse Unit 8 80 R50 II VK32

Timing-Belt Tensioner



For fastening and tensioning the Timing Belt on a sliding carriage or support profile (using Counter-Reverse Unit 8 80 R50). A Tensioning Block (Art. No. 0.0.426.04) is required for each end of the Timing Belt. The number of Fixing Blocks (Art. No. 0.0.426.05) is determined by the application.

8 R50

a = hexagon nut DIN985	M6
b = Hexagon Socket Head Cap Screw DIN912	M6x100

Fastening and tensioning the Timing Belt on a sliding carriage using Tensioning Blocks and Fixing Block and the appropriate bolts.

Where high loads are involved, Tensioning Block 8 and Fixing Block 8 will need to be pinned (dowel ISO 2338-Ø 6 mm). The position of the dowels is indicated by the prepared bores Ø 5.5 mm.

Tensioning the Timing Belt

The loose Timing-Belt Tensioner is pushed under the carriage, joined using the tensioning screws and tensioned.

⚠ The Timing Belt pretension should be more than or equal to the anticipated operating loading. The pretension and operating loading together must not exceed the maximum permissible loading.


To measure the amount of pretensioning L we recommend measuring the amount by which the belt stretches during tensioning.

The minimum required tensioning travel of the Timing Belt has to be calculated to match the operating loading:

$$\Delta L = (F_B \times L) / 1000 \times K$$

L = total length of the Timing Belt in mm
 F_B = (max.) applied load in N
 K = constant of expansion in N ($K = 1,000$ N)

Alignment of Timing-Belt Reverse Unit to the Profile



Fastening location of Timing-Belt Reverse Unit 8 80 R50 II to different profiles, depending on the position of the return timing belt.

Synchronisation




Illustration similar

Connection of Timing-Belt Reverse Units for distances over 500 mm with Synchroniser Shaft Profile VK32 (Art. No. 0.0.463.56).

The Multi-Spline Shaft VK32 (Art. No. 0.0.337.63) components inside the Reverse Unit must be lubricated prior to assembly to prevent fretting. For Reverse Units with multi-spline hubs operated in parallel it will be necessary to adjust the position of the hub to the teeth of the pulley which might be different. This correction has to be carried out for best performance of the drive. The Synchroniser Shaft mounted between the two Reverse Units should be equipped with a Synchroniser Shaft Equaliser Coupling VK32 (Art. No. 0.0.472.29).

These products are content of Section "Mechanical Drive Elements" of the MB Building Kit.

item

item Industrietechnik GmbH
Friedenstrasse 107-109
42699 Solingen
Germany

Phone +49 212 6580 0
Fax +49 212 6580 310

info@item24.com
item24.com



The latest version of these Notes on Use and Installation is available online, in the download section for this product.